



## Installation Instructions

### Cast Stainless Billet Hood Catch

**Part No: 74333 76-95 Jeep Wrangler**

**Part No: 74334 97-06 Jeep Wrangler**

**Part No: 74335 2007-14 Jeep Wrangler**

#### Parts List:

- 1- Set Hood Catches
- 4- Rubber bump stops on 74335 only
- 1- Alcohol pad

#### Tools Required:

- Ratchet
- Extension
- 10mm socket
- 11mm socket
- 13mm socket

#### Installation:

- 1) Remove factory Hood catches
  - a) Open hood and prop
  - b) Remove two 10mm nuts from top hook and remove
  - c) Remove one 13mm nut from lower Catch Strap on fender
- 2) Install Cast Billet Catches. See fig. 1
  - a) Install in reverse of step one.
  - b) Insert stud plate through two holes in Top hook, place on hood and tighten with 11mm nuts.
  - c) Install Lower Catch Strap on fender so pins align and tighten with 13mm nut.
- 3) 74335 requires: 4 Round Rubber Bump stops positioned on flat surface of hood next to catch. Clean flat surface of fender with Alcohol pad, remove adhesive strip and place on fender. See fig. 2

Fig. 1



Fig. 2

