



Installation Instructions

75000,75006,85000,85006
Locking and Non Locking Fuel Doors
97 - 06 TJ/LJ Jeep Wrangler

1) Remove the 4 screws that hold the factory fuel cap bezel to the side of the Jeep. Leave the bezel on the Jeep.

2) Using the 4 screws provided, fit fuel door over the factory fuel bezel and thread the new screws into the factory holes. Ensure fuel door is aligned properly and tighten screws.



Rampage Products 9225 Stellar Ct Unit "C" Corona, CA 92883

Phone: (951) 277-4949 Fax: (951) 277-2295

www.rampageproducts.com