



Installation Instructions

Roll Bar Pad and Cover Kit

Part # 7687 / 7689 / 7690

TOOLS NEEDED FOR INSTALLATION
T-50 & T-40 TORX BITS
3/8 RATCHET
RAZOR BLADE
#2 PHILIPS SCREW DRIVER

PLEASE READ THE INSTRUCTIONS IN THEIR ENTIRETY BEFORE INSTALLING PRODUCT.

1. If you have a hard top on your vehicle, remove it. (Refer to the factory instructions.) If you have a soft top on your vehicle, remove it from the front retainer on the windshield frame. (Refer to the factory instructions.)
2. Remove the bottom bolt on the windshield retaining brackets. The windshield retaining bracket is the bracket that bolts the windshield frame to the dashboard.
3. Wranglers only: remove existing roll bar pad from main bar to expose head of bolt holding windshield brace to the main roll bar. Remove the bolt. Gently lower the windshield frame onto the front hood. (If you have a CJ, skip this step.)
4. Remove the seat/belt mounting bolt from the roll bar.
5. Install the new cover. Start with the main bar, then proceed to the two bottom lengths below the rear braces, then finish with the rear braces. Start the zippers and then twist the pad so the zipper is straight, then continue to zip the pad up completely.
6. Remove the factory front brace covers by sliding them off of the rear portion of the front brace. Install the Rampage Products front brace covers.
7. **CJs only:** Use your finger and feel for the bolt hole the seat belt was bolted into, and cut an "X" with the razor blade. Insert the bolt through this cut and start turning the bolt by hand, then tighten with the ratchet. Repeat on the opposite side.
Wranglers only: Use your finger and feel for the bolt hole with windshield brace was bolted into on the front side of the center hoop, and cut an "X" with the razor blade. Tilt your windshield back up until the windshield brace meets the roll bar. Unzip the roll bar pas enough to insert the bolt under the roll bar pad, then insert the bolt through the cut and start turning the bolt by hand, then tighten with the ratchet. Repeat on the opposite side.
8. Reinstall your soft top or hard top. Refer to the factory instructions.

Rampage Products
9225 Stellar Ave Unit "C" Corona, Ca., 92883
Phone: 951-277-4949
Fax: 951-277-2295
Made in China