



Installation Instructions

75000,75006,85000,85006
Locking and Non Locking Fuel Doors
97 - 06 TJ/LJ Jeep Wrangler

1) Remove the 4 screws that hold the factory fuel cap bezel to the side of the Jeep. Leave the bezel on the Jeep.

2) Using the 4 screws provided, fit fuel door over the factory fuel bezel and thread the new screws into the factory holes. Ensure fuel door is aligned properly and tighten screws.

