



Installation Instructions

X-Over-Caddy™

Part No. 503511 and 503515 All Jeep® CJ& Wrangler



Installation:

- 1) Remove from Box, lay out on flat surface with pouches facing downward.
- 2) Stretch all straps out so they are not twisted
- 3) Install Single front strap through footman loop on the Windshield frame. Do not tighten fully.
- 4) Install the 4 side straps around the front roll bar braces at 90 degrees to the Caddy. Do not tighten fully.
- 5) Install the 2 rear straps around the center hoop of the roll bar. Do not tighten fully.
- 6) Position the X-Over-Caddy on the center line of the vehicle and snug up all the straps. Hook excess strap to the hook and loop sewn to the end of strap to secure it.

Rampage Products
9225 Stellar Court Unit C, Corona, CA 92883-4919, U.S.A.
Phone: (951) 277-4949 Fax: (951) 277-2295 e-mail: info@rampageproducts.net
www.rampageproducts.net
Made in China