

## Installation Instructions

### Jeep YJ & TJ Universal Half Door & Full Door Interior Arm Rest

#### Part # 5952XX & 5953XX

##### Step #1

Remove 2 Torx screws from existing Pull Handle and remove from door.

##### **5952xx Full Door Armrest**

Place pull handle over slots in Armrest insert the 1-1/2" Sheet metal screw with finishing washer through slots and screw into door mount. 5952xx is universal to the Drivers or Passenger side.

##### **5953XX Half Door Armrest**

Position armrest with the cut out slot, closest to the front on the Drivers or Passenger side of vehicle. Armrest can be reversed depending on seat travel requirements.

Place pull handle over slots in Armrest insert the 2" Machine screw with finishing washer through slots and screw into door mount.

Remove  
Torx  
Screws



Position slot closest to the front of the armrest on the Drivers or Passenger side of Vehicle for 5953xx

Rampage Products  
9225 Stellar Court Unit C, Corona, CA 92883-4919, U.S.A.  
Phone: (951) 277-4949 Fax: (951) 277-2295 e-mail: [info@rampageproducts.net](mailto:info@rampageproducts.net)  
[www.rampageproducts.net](http://www.rampageproducts.net)  
*Made in China*